Week 4 – ABB Robot Teaching Machining Processes

Advanced Robotic Systems – MANU2453

Dr Ehsan Asadi, School of Engineering RMIT University, Victoria, Australia Email: ehsan.asadi@rmit.edu.au

- Introduction
- Drilling
- Milling
- Deburring
- Polishing



- Introduction
- Drilling
- Milling
- Deburring
- Polishing



Introduction

- So far, we have learnt how to program the robot to perform welding.
- In the manufacturing industry, robots are also used to perform many other tasks, for e.g. drilling, milling, polishing and deburring.
- In this notes, we will learn some general tips on how to program robots in ABB Robotstudio for these processes.




- Introduction
- Drilling
- Milling
- Deburring
- Polishing



Drilling

- Drilling is a relatively simple process.
- It is done using drill bit attached to a spindle.
 - a) Set a target point perpendicularly above the drilling position.
 - b) Set a target point at the depth of drill.
 - c) Set a lift-off point.








Drilling

- It might not be necessary to calibrate the tool as was shown for the welding torch.
- This is because the tool sits directly along the z-axis of Tool0.
- With respect to Tool0, the tool tip should ultimately be at the position of x=0,
 y=0 and z = some known distance.
- This can be set directly in RobotStudio.






- Introduction
- Drilling
- Milling
- Deburring
- Polishing



Milling


- Milling is somewhat similar to drilling
- It is done using milling cutter attached to a spindle.
 - a) Set a target point perpendicularly above the milling position.
 - b) Set a target point at the depth of mill.
 - c) Move across the workpiece.
 - d) Set a lift-off point.






Milling

 However, depending on the shape of the intended cut, the milling path may be different.






http://www.johnhart.com.au/129-software/hypermill/maxx-machining

https://www.sciencedirect.com/science/article/pii/S0010448502000490



Milling

- It might also not be necessary to calibrate the tool as was shown for the welding torch.
- This is because the tool sits directly along the z-axis of Tool0.
- With respect to Tool0, the tool tip should ultimately be at the position of x=0,
 y=0 and z = some known distance.
- This can be set directly in RobotStudio.





- Introduction
- Drilling
- Milling
- Deburring
- Polishing



Deburring

Deburring means the removal of burrs after some machining operations.





https://www.canadianmetalworking.com/article/fabricating/automated-deburring-basics

 For robotic deburring, it is suggested to use some softer tools which would not damage the workpiece.



https://www.rsa.de/en/products/brushes/ product-finder/deburring/




http://www.abtex.com/fiber-abrasive-finishingsystem-article.html?no_redirect=true



Deburring


- The robot path is as follows:
 - a) Set a target point above the burrs position.
 - b) Set a target point at the depth of burr.
 - c) Move across the workpiece edge.
 - d) Set a lift-off point.





Deburring

- Because the soft tool offers some flexibility, it is also not be necessary to calibrate the tool as was shown for the welding torch.
- With respect to Tool0, the tool frame should ultimately be at the position of x = some known distance, y = some known distance and z = some known distance. The distance can be obtained from rough measurement or CAD.
- This can be set directly in RobotStudio.
- The tool frame should be a little underneath the surface of the tool (as shown in figure), so that the tool "brushes into" the workpiece.





- Introduction
- Drilling
- Milling
- Deburring
- Polishing



Polishing

- Polishing is used to improve the surface quality, for e.g. increase smoothness or visual appearance.
- For robotic polishing, it is suggested to use some softer tools which would not damage the workpiece.



http://www.sterlingtools.com.au/GMFDZ 5060/Mini-Flap-Disc-Quick-Change-%28Roloc-Type%29-50mm-ZK60-Grit/pd.php




https://www.mahanyweld.com/collection s/abrasives-flap-disk



Polishing

- The robot path is as follows:
 - a) Set a target point above the surface.
 - b) Set a target point at the depth of polishing.
 - c) Move across the workpiece surface. Always maintain same angle with respect to surface if possible.

d) Set a lift-off point.




Polishing tool



Polishing

- Again, because the soft tool offers some flexibility, it is not be necessary to calibrate the tool as was shown for the welding torch.
- With respect to Tool0, the tool frame should ultimately be at the position of x = some known distance, y = some known distance and z = some known distance. The distance can be obtained from rough measurement or CAD.
- This can then be set directly in RobotStudio.
- The tool frame should be a little underneath the surface of the tool (as shown in figure), so that the tool "brushes into" the workpiece.





Thank you!

Have a good evening.

